

PA20-GM APPLICATION GUIDE

90308

Make	Model	Year	Applicable Radio	XM Receiver Location	Note
<i>Buick</i>	Enclave	2008	on- Nav on	Right-Rear Q-panel	(1)
	Lucerne	07 - 08	on- Nav on	Left-Rear trunk	(1)
<i>Cadillac</i>	DTS	06 - 08	All	Left-Rear trunk	(1)
	Escalade	07 - 08	All	Behind Glove Box	(1)
	EVS	07 - 08	All	Behind Glove Box	(1)
	EXT	07 - 08	All	Behind Glove Box	(1)
<i>Chevy</i>	Avalanche	06 - 08	All	Behind Glove Box	(1)
	Cobalt	2008	All	Under Rear Deck	(2)
	Equinox	07 - 08	All	Left Rear Q-Panel	(1)
	HHR	06 - 09	All	Right-Rear Q-panel	(2)
	Impala	06 - 09	All	Right Rear Trunk	(1)
	Malibu	08 - 09	All	Under Left-Rear Deck	(2)
	Silverado	07 - 08	All	Behind Glove Box	(1)
	Suburban	07 - 09	All	Behind Glove Box	(1)
Tahoe	07 - 09	All	Behind Glove Box	(1)	
<i>GMC</i>	Acadia	07 - 08	on- Nav on	Right-Rear Q-panel	(1)
	Sierra	07 - 08	All	Behind Glove Box	(1)
	Yukon	07 - 08	All	Behind Glove Box	(1)
	Yukon Denali	07 - 08	All	Behind Glove Box	(1)
<i>Pontiac</i>	Solistice	07 - 08	All	Right Rear Trunk	(2)

Note (1): Order CB-GL29 cable if the car does NOT have XM receiver.

Note (2): Order CB-GL11 cable if the car does NOT have XM receiver.

Cables can be ordered from USA SPEC @626-3363836