

FORD iPod ADAPTER OWNER'S MANUAL

INTRODUCTION

This product allows you to interface your iPod or iPod mini directly to the OEM (factory) radio in select FORD Vehicles. Using this interface, the iPod will take the place of the FORD CD Changer, noted you will see the difference in operations. The radio will be able to directly access your playlist (s), just like changing disc. If any playlist contain more than 100 tracks, the tracks will be divided into sub-folder of 100 tracks each. These folders are referred to as "BANKS".

The CD Changer function of the radio will be utilized to operate the iPod, allowing you to benefit from:

1. Charging of the iPod
2. Control of the iPod using the OEM (factory) radio
3. Direct audio connection for optimal sound quality

If a FORD external CD Changer is present, you must disconnect it before installing this interface.

COMPATIBILITY

Use with one of the following iPod modes:

iPod (G3/G4) and iPod mini models equipped with a dock connector.

Note: The operation and functions of this interface described herein have only been confirmed with the following firmware versions (see apple.com/iPod for firmware updates*)

iPod

firmware v2.2

firmware v3.0 (G4)

iPod Mini

firmware v1.1

*control functions may not remain the same after updating the iPod with firmware not specified in this manual

NAMING OF PLAYLIST(S)

Once your iPod™ or iPod™ mini is connected to the interface, the radio will see all the playlist(s) as CD's. The VW radio will allow a maximum of 6 CDs/playlist (i.e. presets 1 - 6). Therefore, you will need to name your playlist(s) using the letters "CD" and the number corresponding to that preset. **The entire library will automatically be stored in any unnamed/empty playlist (if any playlist is left unnamed/empty).** The following is an example of correct playlist(s) naming:

Preset #'s	Playlist(s) names
Preset 1	"CD1"
Preset 2	"CD2"
Preset 3	"CD3"
Preset 4	"CD4"
Preset 5	"CD5"
Preset 6	"CD6"

The name of the playlist must be exactly as shown, "CD" must be in capital letters, **no spaces between letters and the corresponding number for that preset** must be present. The following is an incorrect way of naming a playlist:

Preset 1	"C_D1"
Preset 2	"CD_ _ _ _"
Preset 3	"C_D1hip-hop"

However, you may add any text after the correct name has been assigned. The following is an example of correct playlist naming with additional text:

Preset 1	"CD1 DCS"
Preset 2	"CD2 Family"
Preset 3	"CD3 Loves"
Preset 4	"CD4 Jazz"
Preset 5	"CD5 Classical"
Preset 6	"CD6 R&B"
Etc	

PLAYBACK FUNCTIONS

Track Up and Down

The radio has "<SEEK>" buttons which will allow you to track up (SEEK ►) and track down (◄ SEEK) through each track on the current playlist. (Beetle radios have separate "<DN/UP>" buttons)

Fast Track Mode

Pressing the "SCAN" button twice (scan on, scan off) will change the "<SEEK>" functions. In this mode, the "<SEEK>" buttons will track up and down in increments of 10. Pressing the "SCAN" button twice (scan on, scan off) will turn off the "Fast Track" mode.

Fast Forward and Fast Rewind

The "<SEEK>" buttons, when pressed and held, will fast forward and fast rewind through the track currently playing.

Note: Performing a fast forward or fast rewind command will cancel "fast track" mode.

SCAN (also used for BANK-VIEW and FAST TRACK modes)

Press the "SCAN" button once and the radio will play 10 seconds of each song in the entire playlist. The radio will continue to play this way until "SCAN" is deactivated (press "SCAN" once).

MIX (Random Play)

Pressing the "MIX" button of the radio will engage the iPod™ into random play mode. While in this mode, the radio will randomly play songs from the entire playlist. The track number will change to 1 just like it does on the iPod™ and iPod™ mini. The radio will continue to play this way until "MIX" is deactivated.

READING THE RADIO'S DISPLAY

Your radio's track number display is only 2 characters long. If a playlist has more than 99 tracks, track numbers roll over. However, you may still keep track of what track number the iPod™ is playing using PIE's special feature called "Bank View" mode.

NOTE: The 99th and 100th song of every "BANK" will be displayed as "TR99". While playing "TR99", press the track up button and track 100 will play (display stays on "TR99").


Bank View Mode

Pressing the "SCAN" button 3 times (scan on, scan off, scan on), the radio's track number display will show you which "BANK" you are currently playing. The "MIX" function must be turned off if it is on. "BANK" numbers are designated as follows:


"TR01"	=	BANK 1	songs 1 - 100
"TR02"	=	BANK 2	songs 101 - 200
"TR03"	=	BANK 3	songs 201 - 300
"TR04"	=	BANK 4	songs 301 - 400
Etc.		Etc.	Etc.

NOTE: When the *FORD iPod Interface* is connected you will **NOT** be able to control your iPod using the iPod buttons.

Radio's display while in normal mode:



Radio's display while in "BANK VIEW" mode:



Revised 7/7/05

© 1995-04 Discount Car Stereo, Inc. All rights reserved. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

iPod™ iPod™ Mini are trademarks of Apple Computers Inc. registered in the USA and other countries.