



BKR-MC

REPLACEMENT MICROPHONE CONNECTING PROCEDURE FOR BECKER HANDS-FREE RADIOS

The BKR-MC aftermarket replacement microphone kit works on select Becker Bluetooth Hands-free ready radios including Traffic Pro, Cascade and others.

Package contents:

Microphone on 10 ft. cable x 1

8-pin BLUE ISO socket x 1

U-shaped visor clip with self-adhesive backing x1

Installation:

Remove radio. Click [here](#) for radio removal instruction




Fig. 1

1. **Connection to radios without optional CD changer, iPod™ remote kit, Aux adapters etc.**
Insert leads as described below to BLUE plug (included in kit), then insert BLUE plug to radio C-2 socket as seen in Fig. 1
2. **Connecting to radios with optional CD changer, iPod™ remote kit, AUX adapter etc.**
Insert leads as described below to OE BLUE plug (already fitted)

Connections:

- a) Insert RED (or white) lead to slot 13 on BLUE plug (See Fig. 2)
- b) Insert BLACK lead to slot 14 on BLUE plug (See Fig 2)



Fig. 2

Warning: Ensure leads are in right slot otherwise a special tool is required to remove from plug