



BKR-MCP

REPLACEMENT MICROPHONE CONNECTING PROCEDURE TO SELECT BECKER HANDS-FREE RADIOS

The BKR-MCP aftermarket replacement microphone works on select Becker Hands-free (Bluetooth) radios including Indianapolis Pro, Grand Prix and others with 2-pin microphone connector.

Warning: The 2-pin microphone input on Cascade radios can only be used for built-in hands-free operation. External hands-free kits must use their own microphone.

Package contents:

Microphone with 9 ft. cable x 1
2-pin plug x 1

Installation:

Remove radio. Click [here](#) for radio removal guide.





Fig. 1

Microphone should be placed to allow for optimum voice recognition. Recommended positions can be seen in Fig. 1

A (visor) **B** (pillar)

Insert cable 2-pin plug to radio microphone connection (release tap facing upwards) See Fig. 2



Microphone connection



Fig. 2