



BLU-CHRY (v 9.30)

QUICK INSTALLATION GUIDE FOR 1995-02 CHRYSLER RADIOS WITH CD CHANGER CONTROLS

created August 19, 2016
Revised: October 15, 2021

PRODUCT SAFETY & DISCLAIMER

READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING, FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY

- This installation guide is provided as a GENERAL installation guide, some vehicles vary and may require additional steps. We do not accept responsibility for third party labor charges or modifications. Exercise due-diligence when installing this product.
- We do not accept any responsibility for vehicle damage or personal injury resulting from the installation of this product.
- Careless installation and operation can result in equipment damage.

Requirements:

CD CHANGER CONTROLLING RADIO

Introduction (version 9.30)

Many older car owners looking for a simple way to play audio devices without replacing the radio will be pleased to find this module. The BLU-CHRY adapter provides a **streaming** solution for any Smartphone, Kindle, Tablet with AZDP profile. A wireless connection means no wires, clutter or complicated setup. The BLU-CHRY plug-n-play solution connects to factory radio 8-pin CD changer port which guarantees to best possible sound and replaces the CD changer (if present).

For this module to work, the 1995-02 square face radio pictures on page 1 with the following buttons:

- a. "Disk ^" printed on preset # 1, and **8-pin** CD changer port. (See Fig. 2)
- b. "Mode/Eject" button, 6 radio presets, Bass and Treble slider controls, "DIRECT DISC SELECT 1-6" above radio presets. (See image on pg. 1)
- c. European (Export) radio models: **PO4704345, PO5269484, PO4671088**

Newest version (9.30): call number announced on car speakers. **Call must be answered through handset.**

See **Frequently Asked question** at the end of this guide for details.

Installation

Radio removal required to gain access to the connector. Vehicle specific radio removal is not part of this guide but available upon request.

1. Connect adapter 8-pin plug (See Fig. 1) to 8-pin "CD" connector on radio (See Fig. 2)



Fig. 1
8-pin plug




Fig. 2
Radio connector

2. Secure adapter box and proceed to next step.

Pairing

The pairing process varies between devices but the basic steps are the same. This process is done upon initial install and will not have to be repeated

1. Turn Ignition and radio "ON"
LED inside adapter will flash (pairing mode)
2. On A2DP device: Go to **Settings, Wireless & Networks, Bluetooth Settings**
3. Select **Bluetooth** and turn on.
4. Then select Bluetooth settings
5. Tap **Scan for devices**.
6. Wait for the Bluetooth device name to appear and select it. (See below)
LED inside adapter will glow steady



Operation

1. Turn ignition to "ACC" and radio "ON"
2. Press "MODE" button on radio to enter changer mode. Radio will display Disc1 Track 1 as seen in **Fig. 3**



Fig. 3

3. Launch Smartphone or Tablet audio application and verify device volume is set to at least 80%
4. Turn radio volume control button to set the playback level.

Warning: Playlist and track selection *NOT* possible from radio buttons. Use smartphone built-in controls and display to access and control audio files and applications

5. Newest version (9.30). If call comes in while streaming, music is muted and call number announced. User may elect to take call using handset.
Note: Background noise may be heard during call number announcement (this is normal)
6. If correct operation is confirmed go ahead and reinstall radio.

Frequent ask questions & troubleshooting

- 1. Will the BLU-CHRY work on all Chrysler with 8-pin “CD connector?”**
NO; the BLU-CHRY works on 3 Chrysler CD changer controlling radios:
#1. **“Square face”** 5 preset radio with “Disk Up” on preset # 1, “Disc down” on preset #5, 8-pin CD changer port. (See image on page 1)
#2. **“Square face”** 6 present radio with “Mode/Eject” button, Bass and Treble slider controls, “DIRECT DISC SELECT 1-6” printed above radio presets.
#3. European (Export) radio models: **PO4704345, PO5269484, PO4671088—refer to white sticker on radio chassis.**
- 2. My radio has a MODE button. Will the BLU-CHRY work?**
Probable not. Radio has to have more than just “MODE” button. Refer to question 1 for additional button/label requirements to guarantee compatibly.
- 3. Can I use the BLU-CHRY to make/receive phone calls?**
NO; The **BLU-CHRY** supports Bluetooth music streaming (A2DP). Does not support hands-free (HPF) profile, however newest version (9.30) supports call number announcement. User must answer call using handset.
- 4. Will I have to disconnect the CD changer?**
YES, the BLU-CHRY uses the 8-pin CD changer port. Any and all factory devices using this port will need to be disconnected. See our [A2D-CHRY](#) to retain use of the CD changer.
- 5. Can I use radio buttons to control songs and text display?**
NO, radio button does not control audio device. You must continue using device built-in control and display just as you would in portable mode.

Disclaimer

- This product has no affiliation with Chrysler
- We’re not liable for misuse of this product.
- We recommend professional installation

Email support@discountcarstereo.com

© 1995-Oct-21 Discount Car Stereo, Inc. All rights reserved. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.