



## CHRY98-AUX

### QUICK START AUXILIARY INPUT INSTALLATION GUIDE FOR CHRYSLER 1998-01 RADIOS WITH CD-C BUTTON

Created May 11, 2017  
Revised February 9, 2025

## PRODUCT SAFETY & DISCLAIMER

READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING, FAILURE TO DO SO MAY CAUSE PERSONAL INJURY OR DAMAGE TO PRODUCT AND/OR PROPERTY

- This installation guide is provided as a GENERAL installation guide, some vehicles vary and may require additional steps. We do not accept responsibility for third party labor charges or modifications. Exercise due-diligence when installing this product.
- We do not accept any responsibility for vehicle damage or personal injury resulting from the installation of this product.
- Careless installation and operation can result in equipment damage.
- Careless installation and operation can result in equipment damage.

## Requirements:

Radio with CD changer controls (CD-C button)

## Introduction:

This simply Auxiliary input adapter allows users to connect and play audio devices with a 3.5mm jack to select 1998-01 Chrysler radios with **CD-C button** on faceplate. Connect installation harness 8-pin plug to the radio 8-pin CD changer port and begin enjoying music stored on smart devices or applications from any internet connected smartphone, tablet, laptop etc. The CHRY98-AUX replaces factory CD changer (if present) and compatible only with radios with **CD-C button**.

The built-in USB charging port provides 5V/2.1A charging power to keep devices charged while on the radio. TRSS support allows radio or steering wheel SEEK button to change tracks. **(Vehicle must have steering wheel controls and device must support TRSS)**

## Introduction:

1. Remove radio from dash to gain access to connector.  
*Vehicle specific radio removal is not part of this guide but may be available upon request.*

2. Disconnect any Chrysler accessory connected to radio 8-pin connector (See **Fig. 2**)
3. Connect adapter harness 8-pin plug (See **Fig. 1**) to radio 8-pin "CD" port (See. **Fig. 2**)



Fig. 1



Fig. 2

Radio connector

4. Connect one end of supplied audio cable (See **Fig. 3**) to input jack on adapter (See **Fig. 4**) and route audio plug to dashboard or wherever audio device will reside.




Fig. 3



**Fig. 4**  
3.5mm jack

5. Connect installation harness 16-pin plug (See **Fig. 5**) to module 16-pin connector (See **Fig. 6**)



**Fig. 5**



**Fig. 6**

## Optional USB extension cable installation

**Notes:** 1. Optional 6 ft. USB dash mount extension cable is not required for operation; however, it extends USB charging port (See **Fig. 9**) to dashboard, glovebox etc.

2. **The USB port supports software updates and charging only**

1. Drill a  $\frac{3}{4}$ " hole to dash or panel using a step drill bit or equivalent (See **Fig. 10**)

As an alternative; use the included bracket (See **Fig. 14a**) to mount USB without drilling.



**Fig. 7**

2. Fish USB cable terminal (See **Fig. 11**) through hole created in step 1 and plug into USB port on module (See **Fig. 8**)



**Fig. 8**  
USB cable



Fig. 9

3. Snap header (See Fig. 10) to surface until flush (See Fig.11)



Fig. 10



Fig. 11



Fig. 12

Tuck and secure any extra wires from moving parts and proceed to next step

## Operation

1. Turn ignition and radio "ON"
2. Press "CD-C" button on radio (See Fig. 14). Radio display changes to Fig. 15



Fig. 14



Fig. 15

3. Connect audio cable 3.5mm plug to audio device and place audio device in playback mode. If playback is distorted lower audio device volume or if inaudible, raise volume on device. Ensure audio device volume is set to 80% or more.
4. If audio device support TRRS, **and vehicle has steering wheel controls**; use radio or steering wheel SEEK button to change tracks on the fly. (See Fig. 16)



Fig. 16

5. If correct operation is confirmed go ahead and reinstall the Radio.

## Frequently asked questions

1. **Will the CHRY98-AUX work on all Chrysler 8-pin radios?**  
**NO;** Works on all Chrysler radios with a **CD-C** button on faceplate
2. **My radio also has a “rounded face” and a Mode button. Will the CHRY98-AUX work?**  
**NO,** 2002+radios with Mode button requires our [CHRY02-AUX](#).
3. **Can I use the CHRY98-AUX to make/receive phone calls?**  
**NO;** The **CHRY98-AUX** is an auxiliary input adapter and as such it does not support hands-free calls; however, speakerphone mode allows caller to be heard on car speakers.
4. **Will I have to disconnect the remote CD changer?**  
**YES,** this adapter uses the 8-pin changer port. Any and all devices using this port will need to be disconnected.
5. **Can I use the radio buttons to control songs and display text?**  
**NO.** Chrysler radios do not support text display but if audio device support **TRRS and vehicle has steering wheel controls;** use radio or steering wheel SEEK buttons to track up and down within playlist.

### Disclaimer

- This product has no affiliation with Chrysler
- We're not liable for misuse of this product.
- We recommend professional installation

**email support@discountcarstereo.com**

© 1995-Feb-25 Discount Car Stereo, Inc. All rights reserved. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.