


INSTALLATION DIAGRAM FOR FRDW-AUX, AUXILIARY INPUT ADAPTER



NOTE: LOCATION OF THE DATA CONNECTOR MAY VARY FROM VEHICLE TO VEHICLE.